

NMR-MICP Integration & Permeability Estimation: A New Free Petrophysics Software

*P.V. Mesquita, R. B. V. Azeredo, E. H. Rios,
A. Souza, B. A. C. Silva, B. M. Faria, A. Boyd*




Outline

- Background Theory
- Motivation & Goals
- Main software features
- Conclusions and considerations for the future



NMR in Formation Evaluation

Provides a single measurement (T2 distribution), can be used to estimate porosity (ϕ), pore size distribution (PSD), irreducible water saturation (SWI) and Permeability (k) of formations



(1) <http://accutech.metadot.com/index.pl?r=1>

(2) www.spe.org/jpt/article/10327-technology-update-24



NMR Petrophysics

$$\frac{1}{T_2} = \frac{1}{T_{2\text{surface}}} = \rho_2 \left(\frac{S}{V} \right)_{\text{pore}} \rightarrow$$



Estimating permeability (k)

$$k = a\phi^b \left(\frac{V}{S} \right)_{\text{pore}}^c \quad \& \quad \left(\frac{V}{S} \right)_{\text{pore}} = \rho_2 T_2$$

$$k_{NMR} = a\phi^b (\rho_{eff} T_{2rep})^c$$

$$k_{SDR} = a'\phi^b (T_{2logmean})^c$$


Is Surface Relaxivity ρ_2 homogeneous throughout a formation ?




(3) From "NMR Logging - Principles and Applications"

MICP

- Laboratory Experiment to obtain the Cappillary Pressure curve from rock samples, by injecting Mercury.
- The Cappillary Pressure curve can be converted to a "pore throat size" distribution.
- This distribution can be used to estimate permeability and several other types of petrophysical data.
- $K_{MICP} = a\phi^b R_{trep}^c$
- Can't be used downhole.
- Destroys the sample.



$$R_t = \frac{2\sigma|\cos\theta|}{P_c}$$



NMR-MICP Integration


MARSCHALL, D. et al: **Method for correlating NMR relaxometry and mercury injection data**. SCA Conference, 9511, p. 1-12, 1995.

- Found a simple way to correlate the PTD from MICP with the pseudo-PSD from NMR.

$$R_t = \gamma \rho_{eff} T_2$$



$$K_{NMR-MICP} = a\phi^b (\rho_{eff} T_{2rep})^c$$



NMR-MICP Integration

RIOS, E.H.; et al. **NMR permeability estimators under different relaxation time selections: a laboratory study of cretaceous diagenetic chalks**. SPWLA, 55th Annual Logging Symposium, 2014

- Different metrics to obtain the **representative** value from T2 and Rt distributions.


- $$K_{NMR} = \alpha \phi^b T_{2rep}^c$$

$$K_{MICP} = \alpha \phi^b R_{trep}^c$$

- Sized-Scaled estimators – Simple match between MICP (PTD) and NMR (PDS).

- $$S_{HGrep} = \frac{R_{trep}}{T_{2rep}}$$

$$K_{SHG} = \alpha \phi^b (S_{HGrep} T_{2rep})^c$$



Motivation

N core/log entries with:

- N* porosities
- N* permeabilities
- N* T₂ distributions
- N* Rt distributions
- 2*N* * 3 pythagorian means
- 2*N* * 19 cutoffs (5% to 95%)
- N* * 484 sHgs matches
- N* NMR-MICP ρ_{1,2eff}
 - different pore shapes (γ)

Which is best?

And why?



$$K_{NMR} = \alpha' \phi^b (T_{2rep})^c$$

$$K_{MICP} = \alpha \phi^b (R_{trep})^c$$

$$K_{SHGrep} = \alpha \phi^b (S_{HGrep} T_{2rep})^c$$

$$K_{NMR-MICP} = \alpha \phi^b (\rho_{2eff} T_{2rep})^c$$

Different a,b,c:

- Constant
- Constrained
- Unconstrained

Then Calculate:

- R²
- Standard Error



Goal

- Handle big datasets RCA and SCAL data or log.
- Automate calculations of all required parameters (means, cutoffs and ρ values) from NMR and MICP distributions.
- Enable fast evaluation of these permeability estimators.
- Facilitate the interpretation of results and comparison with the others models.




Speed-up the process for studying and evaluating these permeability estimators.




1- Sample Management

- Samples' Table for selecting subsets of data
- Interactive Cross-Plots
- Use the "Group" to segregate different formations, etc...




1- Sample Management



2- Automation

- NMIP imports all input data from Excel spreadsheets:
 - NMR T2 distributions
 - MICP Rt distributions
 - Routine Core Analysis (porosity, absolute permeability, etc...)
 - Any other petrophysical input.
- NMIP automatically tries to calculate:
 - All Pythagorean means (harmonic, geometric or “logarithmic”, arithmetic).
 - Saturations cutoffs from 5% to 95%, with a 5% step
 - sHg matches with all possible combinations
 - NMR-MICP direct matching (Cross-Correlation)
- Create arbitrary cutoffs from NMR or MICP data.
- Run Custom Python Scripts.
- Possibility to edit the NMR-MICP match.



3- Permeability ESTIMATION

The screenshot shows the 'Estimators' software window. At the top, the equation $K_{nmr} = a\phi^b(param0 * param1)^c$ is displayed. Below it, it indicates '19 samples' and 'Groups: Carbonate, Sandstone'. The 'Porosity variable' is set to 'Porosity', ranging from 6.5% to 30.5%. The 'Permeability variable' is 'Kabs', ranging from 0.09mD to 3900.0mD.

There are two main panels for defining estimators: 'Add multiples estimators' and 'Add custom estimator'. The 'Add custom estimator' panel shows 'Name: Custom Estimator' and 'Define: "a" "b" "c"' with input fields for '1,0,4,0' and '2,0,3,0'. A 'Processing Queue' window is overlaid, showing 'Process running on 8 cores', 'Time Left: 44 seconds', and 'Estimators per Second: 264.0'. The queue lists 22 items, with item 21 highlighted.

At the bottom right, there are logos for 'RIO OIL & GAS 2016 EXPO AND CONFERENCE' and 'ibp'.

4- Results

The screenshot shows the 'Results' software window. At the top, the equation $K_{nmr} = a\phi^b(param0 * param1)^c$ is displayed. Below it, a table lists 32 rows of results with columns for 'N#', 'R^2', 'SE', 'a', 'b', 'c', 'param0', 'param1', 'Num.', and 'Name'. The table contains numerical values for each parameter across the 32 rows.

Overlaid on the table is a scatter plot titled 'Kabs X param0' showing 'Estimated Permeability (mD)' on the y-axis (log scale from 10⁻¹ to 10⁴) versus 'Absolute Permeability (mD)' on the x-axis (log scale from 10⁻¹ to 10⁴). The plot shows data points for 'Carbonate' (blue dots) and 'Sandstone' (yellow dots) with a linear regression line. The regression statistics are: $R^2 = 0.971$, $SE = 1.678$ mD, $a = 261.03$, $b = 2.001$, $c = 2.156$.


At the bottom right, there are logos for 'RIO OIL & GAS 2016 EXPO AND CONFERENCE' and 'ibp'.

4- Results


$$k_{NMR} = a\phi^b(1.0 * T_{2cutoffs})^c$$

$$k_{NMR-MICP} = a\phi^b(\rho_{eff} * T_{2cutoffs})^c$$

$$k_{SHg_{geo}} = a\phi^b(S_{Hg_{geo}} * T_{2cutoffs})^c$$



K estimation improved



Conclusions

- Success in accomplishing our goals.
- Positive feedback from pilot users.
- Project is open for ideas and suggestions.
- UFFLAR will register it as a free software.



Acknowledgments

- **UFFLAR - UFF**
- **BG**
- **SCHLUMBERGER**
- **ANP**
- **RIO OIL AND GAS**



Thank you!




Email: pedroviannamesquita@gmail.com



NMIP characteristics


- Written in python 2.7, using the default GUI API "Tkinter"
- Uses some of python's free scientific modules:
 - Numpy – for fast numerical calculations.
 - Scipy – collection of mathematical algorithms (interpolation, minimization)
 - Matplotlib – for creating interactive plot figures.
- Imports and exports core data using excel files (convenient).
 - Modules: xlswriter, xlrd and xlwt
- Online license verification is required on startup (although, the software is completely free).
- Only works on Windows (for now).





ρ_2 from DT2 maps

- Extraction of the surface relaxivity ρ_2 from Diffusion T2 maps, by fitting a model to the logmean of a DT2 Map.



$$K_{NMR} = \alpha' \phi^b (\rho_{1,2} T_{2rep})^c$$

PERMEABILITY PREDICTION IMPROVEMENT USING 2D NMR DIFFUSION-T₂ MAPS

Andre Souza¹, Giovanna Carneiro¹, Lukasz Zielinski², Rafal Polinski³, Lawrence Schwartz⁴, Martin D. Hurlimann⁵, Austin Boyd⁶, Edmilson Helton Roos⁷, Bernardo Coutinho Camilo dos Santos⁸, Willian Andrighetto Trevisan⁹, Vinicius de Franca Machado⁹, Rodrigo Baqueira de Vasconcellos Azeredo⁹

- ¹ Schlumberger Brazil Research and Geoeengineering Center, Rio de Janeiro, RJ, Brazil.
- ² Schlumberger Houston Formation Evaluation Center, Houston, TX, USA.
- ³ Schlumberger Brazil Waveline, Rio de Janeiro, RJ, Brazil.
- ⁴ Schlumberger-Dell Research Center, Cambridge, MA, USA.
- ⁵ Petrobras Research and Development Center, Rio de Janeiro, RJ, Brazil.
- ⁶ Federal Fluminense University, Niteroi, RJ, Brazil.

Copyright 2013, held jointly by the Society of Petrophysicists and Well Log Analysts (SPWLA) and the submitting authors. This paper was prepared for presentation at the SPWLA 54th Annual Logging Symposium held in New Orleans, Louisiana June 22-26, 2013.


ABSTRACT

When estimating permeability (k) from NMR logs, a key assumption is that the surface relaxivity (ρ_2) parameter, which scales the relationship between transverse relaxation time (T_2) and the surface-to-volume ratio (S/V) of the pore system, remains constant. With this assumption, the ρ_2 parameter can be accounted for in the pre-multiplier of the SDR permeability equation. However, the presence of clays and/or heavy minerals in complex reservoirs can have a significant effect on ρ_2 , and the permeability estimate can be significantly improved if this variation is accounted for. Recently, Zielinski and coworkers proposed a method for deriving ρ_2 from the two-dimensional (2D) diffusion-relaxation time maps, or D - T_2 maps, as an alternative to the traditional methods that rely on the matching NMR T_2 distributions and mercury porosimetry (MCP) or BET surface area measurements. This methodology is based on the fact that the translational self-diffusion coefficient (D) of a fluid saturating a porous media has its diffusional displacements restricted by collisions with the pore walls, so that D becomes a function of the pore size distribution, i.e. the T_2 distribution. In the present work we applied this novel approach for obtaining ρ_2 directly from NMR measurements and used it to improve the classical SDR permeability estimator. The equation used to estimate permeability with this new methodology was called k_p . We have applied this improved estimation technique to a set of benchmark quarried rock cores, whose results have shown a significant decrease in data dispersion and in the predicted error, when compared to the classical SDR equation. The ability to acquire D - T_2 correlation maps downhole makes the new methodology presented here very promising in heterogeneous wells where previous estimators show sometimes poor correlations.




Custom Interactive Plots


- Set plot "configurations" to produce custom interactive figures with available data
- The configurations can also be stored, shared and reused.



Swap between samples



Swap between samples



Swap between samples

